

Product Safety

SAFETY INSTRUCTIONS

- Before each use, check for a secure fit, correctly joined sections and any damage.
- Use only as intended to help robot vacuum cleaners and robot mops cross door thresholds and similar changes in floor height.
- The ramp must be fully supported and rest securely on a level surface with sufficient slip resistance.
- For multi-part ramps, all dovetail joints must be fully engaged. Do not use if individual sections come loose or move against each other.
- Stop using any damaged, broken or deformed parts.
- Do not modify, machine or use the product for purposes other than its intended use.
- Do not step on the ramp or load it with body weight. Do not use it as a ramp for people or as a step.
- Do not use the product near open flames or other strong heat sources.
- Avoid prolonged exposure to direct sunlight.
- For indoor use only.
- Keep away from children. Not a toy.

INSTALLATION & USE

- Position the ramp directly in front of the threshold, as flush against it as possible.
- Before use, ensure that the ramp cannot slip, tip or shift while the robot crosses it.
- For multi-part versions, fully connect all sections using the dovetail joints provided.
- Supervise the first few crossings by the robot vacuum cleaner or robot mop.
- If the ramp slips, tips, a joint comes loose or the robot moves unusually, stop using it and check the positioning and connections of the ramp.
- Use the ramp only within its specified dimensions and for its intended purpose.